


## Checking the Package Contents

- 1 Scanner
- 2 USB Interface Cable
- 3 Stand
- 4 CanoScan Setup Utility CD-ROM
- 5 Quick Start Guide



## Installing the Software

- Do NOT connect the scanner to a computer before installing the software.
- Quit all running applications before installation, including anti-virus software.
- For Windows 2000/XP, log in as an administrator to install the software.

### 1 Place the CanoScan Setup Utility CD-ROM in the drive.

CanoScan Setup Utility program starts.

- For Macintosh: Double-click the [Setup] icon. Enter the administrator ID and password on the authentication dialog box.

### 2 Click [Easy Install] on the main menu.

### 3 Click [Install] to start installation.

Carefully read the License Agreement, and then click [Yes] to proceed. Follow the on-screen instructions to perform the installation.

All the software programs and on-screen manuals will be installed on your computer.

### 4 When the Information dialog is displayed, click [ok] to restart your computer.

- For Macintosh: Skip this step and go to the step 5.

### 5 Follow the on-screen instructions to register your product.

### 6 When the installation is complete, click [Exit].

- For Macintosh: Click [Restart] to restart your computer.




## Preparing the Scanner

### 1 Slide the lock switch on the bottom of the scanner toward the unlock mark (🔓).

- Always lock the scanner when carrying or transporting it.

### 2 Connect the scanner to the computer with the supplied USB cable.

- Only use the USB cable provided with the scanner. Use of other cables may lead to a malfunction.
- The scanner does not have a power switch. The power is activated as soon as the computer is turned on.
- When the scanner is connected to the USB 1.1 port on Windows XP and "HI-SPEED USB Device Plugged into non-HI-SPEED USB Hub" message appears, ignore the message. The scanner operates in this condition without problems.



## Try Scanning

### 1 Place a document on the document glass and close the document cover.

### 2 Start ArcSoft PhotoStudio.

For Windows: Select [start]-[(All) Programs]-[ArcSoft PhotoStudio 5.5], then click [PhotoStudio 5.5].  
For Macintosh: Open [Applications]-[PhotoStudio] folders, then double-click the [PhotoStudio] icon.

### 3 Click [File] menu, [Select Source] and select the scanner model.

For Windows: Do not select the one that includes [WIA] in the model name.

### 4 Click the acquire icon to start ScanGear.



### 5 Select the type of document you are scanning in [Select Source] and click [Preview].

### 6 Click [Scan] to start scanning.

- Do not move the scanner while it is operating.

### 7 When prompted to close ScanGear, click [OK].

### 8 Save the scanned image in ArcSoft PhotoStudio and close the window.



## Using the Scanner Buttons

### COPY Button

Prints (copies) the scanned image with a printer.

### PDF Button

Saves the scanned image as a PDF file.


### PHOTO Button

Opens the scanned image in the bundled application program, ArcSoft PhotoStudio.

### E-MAIL Button

Attaches the scanned image to a new e-mail message.

- For Mac OS X 10.3/10.2.8: Refer to Troubleshooting in the Scanning Guide (on-screen manual) before using.



Refer to the Scanning Guide (on-screen manual) for further information about ScanGear, CanoScan Toolbox, Scanner Buttons, Troubleshooting and Setting the Stand. To start the Scanning Guide, double-click the on-screen manual icon on the desktop.

In this guide, Windows XP screen shots are used to illustrate explanations common to all operating systems.

## Specifications

		<b>CanoScan LiDE 70</b>
<b>Scanner Type</b>		<b>Flatbed</b>
<b>Scanning Element</b>		<b>CIS (Color Contact Image Sensor)</b>
<b>Light Source</b>		<b>3-color (RGB) LED</b>
<b>Optical Resolution *1</b>		<b>2400 x 4800 dpi</b>
<b>Selectable Resolution</b>		<b>25-19200 dpi (ScanGear)</b>
<b>Scanning Bit Depth</b>	<b>Color</b>	<b>16 bit input/16 bit or 8 bit output for each color</b>
	<b>Grayscale</b>	<b>16 bit input /8 bit output</b>
<b>Scanning Speed *2 (Photo or Document)</b>	<b>Color</b>	<b>8.6 msec./line (1200 dpi), 17.3 msec./line (2400 dpi)</b>
	<b>Grayscale, B&amp;W</b>	<b>2.9 msec./line (1200 dpi), 5.8 msec./line (2400 dpi)</b>
<b>Preview Speed *2*3</b>		<b>Approximately 9 sec.</b>
<b>Interface</b>		<b>USB 2.0 Hi-Speed</b>
<b>Maximum Document Size</b>		<b>A4/Letter: 216 x 297 mm</b>
<b>Scanner Buttons</b>		<b>4 buttons (COPY, PHOTO, PDF, E-MAIL)</b>
<b>Operating Range</b>	<b>Temperature</b>	<b>5°C to 35°C (41°F to 95°F)</b>
	<b>Humidity</b>	<b>10% to 90% RH without condensation formation</b>
<b>Power Requirements</b>		<b>Supplied via USB port (No external adapter required)</b>
<b>Power Consumption</b>		<b>In operation: 2.5 watts maximum, Stand-by: 1.6 watts</b>
<b>Maximum Exterior Dimensions</b>		<b>258 x 374 x 40 mm (10.2 x 14.8 x 1.6 in.)</b>
<b>Weight</b>		<b>Approximately 1.7 kg (3.8 lbs.)</b>

\*1 Optical Resolution represents the maximum sampling rate based on ISO 14473.

\*2 The fastest speed in USB 2.0 Hi-Speed mode on Windows PC. Transfer time is not included. Scanning speed varies according to the document types, scan settings, or specifications of the computer.

\*3 Calibration processing time is not included.

- Specifications are subject to change without notice.

Model Number: K10292 (CanoScan LiDE 70)

### FCC Notice (U.S.A. Only) Model Number : K10292

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Use of a shielded cable is required to comply with Class B limits in Subpart B of Part 15 of the FCC Rules.

Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment.

Canon U.S.A., Inc.  
One Canon Plaza  
Lake Success, NY 11042  
1-516-328-5600

### European Union (and EEA) only.



This symbol indicates that this product is not to be disposed of with your household waste, according to the WEEE Directive (2002/96/EC) and your national law. This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, approved WEEE scheme or your household waste disposal service. For more information regarding return and recycling of WEEE products, please visit [www.canon-europe.com/environment](http://www.canon-europe.com/environment).

(EEA: Norway, Iceland and Liechtenstein)

### For Customers in Europe, Middle-East, Africa and Russia only

For Canon Customer Support contacts, please see the back cover of the European Warranty System (EWS) Booklet or visit [www.canon-europe.com](http://www.canon-europe.com).

### Warning

When you use this product, you should pay attention to the following legal issues:

- Scanning of certain documents, such as bank notes (bank bills), government bonds and public certificates, may be prohibited by law and may result in criminal and/or civil liability.
  - You may be required under law to obtain authorization from a person possessing copyrights or other legal rights to the item being scanned.
- If you are uncertain of the legality of scanning any particular item, you should consult your legal adviser in advance.

- Adobe® and Adobe® RGB (1998) are either registered trademarks or trademarks of Adobe Systems Incorporated in the U.S. and/or other countries.
- Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the U.S. and/or other countries.
- Macintosh® and Mac® are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.
- ©ArcSoft, Inc. All rights reserved for PhotoStudio.
- Other names and products not mentioned above may be registered trademarks or trademarks of their respective companies.